

## Juki Home Overlocker Sewing Machine Accessories List

Description	Picture	Explanation	Model
Blind Stitch Presser Foot ( For Right Needle )		For making blind hems	MO-735/734DE/655 /654DE/644D/623
			Part No. A98106340A0A
Universal Blind Stitch Presser Foot ( For Right & Left Needle )		For making blind hems	MO-735/734DE/655 /654DE/644D/644
			Part No. A95216340A0A
Elasticator Presser Foot		To attach elastic tape to stretch fabrics	MO-735/734DE/655 /654DE/644D/623
			Part No. A98156550A0A
Cording Presser Foot		For attaching nylon string or wire on edge of fabrics	MO-735/734DE/655 /654DE/644D/623
			Part No. A98206550A0A
Beading Presser Foot		For attaching pearls and beading with overlock stitching	MO-735/734DE/655 /654DE/644D/623
			Part No. A98706340A0A
Curved Beading Presser Foot		For attaching pearls and beading on a curve	MO-735/734DE/655 /654DE/644D/623
			Part No. A95116340A0A
Piping Presser Foot		For sewing piping	MO-735/734DE/655 /654DE/644D/623
			Part No. A98656550A0A
Gathering Presser Foot		For gathering and sewing with differential feed	MO-735/734DE/655 /654DE/644D
			Part No. A98606550A0C
Coverstitch Hem Guide		For guiding folded hems for perfectly placed coverstitching	MO-735
			Part No. A9140C090B0